

New parameter in Host Drive Manager config sample file:

```
#
# Number of seconds to wait in order to check if Media Manager IP
# address responds to a ping on the network. This check can be
# disabled by setting timeout=0 (default).
#
timeout=0

#
# Enable/disable IPv6 support (false|true).
# Set variable to true for connecting to MediaManager using IPv6
# (otherwise IPv4 is used).
#
ipv6support=false

#
# flag to control the usage of the driver which will be used by HDM
# false = default use generic driver    true = use IBM atape driver
#
useibmdriver = false

#
# Locale settings. If not set the default settings are: language=en, country=US
#
language = en
country = us
```

Removed parameter in Host Drive Manager config sample file:

```
#
# enable/disable checking of the currently loaded pcl true/false
# only for IBM drives, on none IBM drives the check is automatically disabled
#
checkloadedcartridgepcl = false
```